

Instructions for the readjustment of thermometers and hygrometers

Thermometer with Capillary

Sometimes the liquid in the glass tube (capillary) will have become split or separated during transport. It is possible to force the liquid together again by shaking the thermometer strongly in a downward direction.

Thermometer with Needle

The thermometer has already been adjusted in the factory. Should you wish to check the thermometer, place it next to a well-calibrated instrument for half an hour. Any correction can then be made using a screwdriver at the rear of the thermometer.

Hygrometer

The hygrometer indicates the atmospheric humidity in %. In order that the device continues to work reliably in the long term, we recommend that it be regenerated regularly, at least once a year. To do this, wrap the instrument in a moist piece of cloth for 30 minutes. The hygrometer should then indicate 94-96 %. If this is not so, the instrument can be readjusted at the rear by using a screwdriver.